


How to Use the DocuPen



1. Hold document with thumb and index finger on flat surface
2. Position the DocuPen with LED's to your left and align it at the top of your document
3. Press the button once for normal resolution , or press the button twice for high resolution setting and start gliding the DocuPen down your document

Normal Resolution Mode



High Resolution Mode



4. If red lights blink, then slow down, if you scan too slow, the scanner will turn off
5. Do not stop, lift or twist the DocuPen while scanning
6. When done scanning, LEDs will blink to save into memory
7. Scanner will now turn off

Software Installation

*Note: Please check www.planon.com for latest software & driver updates

Install PaperPort from CD
Instal CP2101 Driver and PenTWAIN Driver from CD

Do NOT attach DocuPen to your PC before installing the drivers

For more details please read the PDF DocuPen Manual on the CD or online.

Do NOT attach DocuPen to your PC before installing the drivers

For Technical Support:

North American Toll Free #: 1-877 DOCUPEN (3628736)
Tel: 1-905-607-3926

PLANON
Easier. The Way We Work